

## OPTIONAL CONNECTION TO HANCOCK RECREATION CENTER AMPLIFIER

- ❖ Connect AC power to the computer. Plug the power adapter into the power strip and then into the power input port on the back edge of the computer.
- ❖ Connect the computer to the Hancock amplifier with the signal cable. Plug the 1/8" stereo audio cable (mini plug) end into the port on the left edge of the computer with the headphones logo. Plug the RCA plugs into the Hancock amplifier as shown in the picture below.



NOTE: Using this procedure means that any equalization of the signal needed for a particular tune must be done on the main channel of the Hancock amplifier, which is generally not practical during a dance program if different tunes require different equalizations.

- ❖ Connect the mouse to the computer. Plug the USB end of the mouse cable into a USB port on the right edge of the computer.